LifeFitness

TREADMILL T9E



Customer Support Services
PARTS MANUAL

Touch-Up Paint	Color	Container
0017-00008-0204	Arctic Silver	Spray Can
0017-00008-0205	Arctic Silver	.5 oz Bottle
0017-00008-0206	Arctic Silver	.33 oz Pen

Manual/Video	Part Number
Operation Manual, Eng	M051-00K60-A062
LCD Service Manual	M051-00K32-A011
Service Manual	M051-00K60-A053

PAGE

FRAME ASSEMBLY 4

CONSOLE ASSEMBLY 5

CONSOLE COMPONENTS 6

HANDRAIL ASSEMBLY 7

COVERS, END CAPS, HARDWARE 8

BELT, DECK, REAR ROLLER 9

WAX/LIFT ASSEMBLY 10

MOTOR CONTROLLER ASSEMBLY 11

LIFT MOTOR & FRAME 12

DRIVE MOTOR ASSEMBLY 13

LEVELER ASSEMBLY 14

FRONT ROLLER ASSEMBLY 15

ERGO BAR W/LIFEPULSE 16

POWER COMPONENTS 17

CABLE 18


Anti-Static Tinsel
0K58-01102-0001
Tinsel Spring
0017-00009-0901
Anti-Slip Rail
0K58-01306-0000 (2)
Static Brush
0K58-01263-0001
Screw
0017-00101-1193
Drive Belt
0K60-01205-0001
Drive Motor
Assembly
Lift Motor
and Frame
Grommet
0017-00042-0320
Front Roller
Assembly



Part number	Description
AK60-00156-0001	CONS NTSC ENG+MET 120/60 DOM
AK60-00157-0002	CONS PAL ENG+MET 230/50 CONT
AK60-00157-0001	CONS PAL-1 ENG+MET 240/50 UK
AK60-00157-0002	CONS PAL ENG+MET 240V+ AUS

TREADMILL T9E
Console Components

T9E-0_ _ _- 02
SN TTG100000



Hardware Bag Assembly
AK60-00173-0000




Motor Cover Screws (4)
0017-00101-1772
Motor Cover
AK60-00164-0000
Felt Strip - 28”
0017-00081-0294
Flex Deck Decals(2)
0K60-01197-0000
Front End Cap (2)
0K58-01267-0000
End Cap Screws (4)
0017-00101-1772
Front Cover
0K58-01266-0000
Screws (4)
0017-00101-1771
Bug Medallion Assembly
AK58-00245-0000


Striding Belt
0K60-01206-0000
Belt Limit Label, LT
M051-00K58-A101
Deck Mounting Screws (4)
0017-00101-1775
Deck
0K60-01204-0000
TECSPAK Mounting Screw (8)
0017-00101-1652
TECSPAK Spring (8)
0K40-01026-0002
Caution Label
M051-00K60-A063
Belt Limit Label, RT
M051-00K58-A100
TECSPAK Tinnerman Clip (4)
0017-00103-0198
Washer (8)
0017-00104-0101
Grommet (2)
0017-00042-1147


Screw
0017-00101-1776
Round Grommet
0017-00042-0326
Washer
0017-00104-0043
Square Grommet
0017-00042-1147
Rear Roller Guard, LF
AK58-00360-0002
Rear Roller
0K58-01002-0000
Rear Roller Guard, RT
AK58-00360-0001
Rear Roller
Adjusting Screws
0017-00101-1850
Roller Guard Screw (4)
0017-00101-1776


Spacer (3)
0017-00042-1149
Locking Nut (3)
0017-00103-0052
Pin Collar Spacer (3)
0017-00042-1070
Motor Capacitor
PCB Mounting
Screw (4)
0017-00101-1253
Motor Capacitor
PCB Assembly
B084-92241-A000
Wax Lift Mounting Screw (3)
0017-00101-1641
Mounting Bracket
0K58-01316-0000
Wax/Lift PCB
A084-92253-A002
Plastic Grommet (4)
0017-00042-0821

AK60-00171-0002 (120v/60Hz)
AK60-00171-0003 (230v/50Hz)
AK60-00171-0003 (240V/50Hz and 240+ AUS)




Lift Motor Hex Bolt
0017-00101-1021
Lift Frame End Cap
0017-00042-1076
Lock Nut
0017-00103-0025
Line Cord Clip
0017-00042-0840
Vinyl Cap
0017-00042-1075
Wheel
0K58-01071-0000
Phillips Screw
0017-00101-1612
Washer
0017-00104-0189
Lift Frame
0K58-01066-0000
Hex Screw (2)
0017-00101-1777
Flat Washer (2)
0017-00104-0259
Bronze Sleeve (2)
0K58-01089-0000
Lock Nut (2)
0017-00103-0285


Cotter Pin
0017-00007-0208
Lift Motor
0K58-01062-0000
Clevis Pin
0017-00007-0214


Motor w/Caution Label
AK60-00168-0000
Poly-V Pulley
0K58-01057-0001
Slotted Hex Screw (2)
0017-00101-0975
Speed Sensor Assembly
AK58-00073-0001
Sensor Wheel
Mounting Screw (3)
0017-00101-1631
Locking Nut (4)
0017-00103-0027
Washer (4)
0017-00104-0409
Sensor Wheel
0K58-01094-0000
Insulating Shoulder
Washer (4)
0K58-01255-0000
Insulating Pad (2)
0K58-01256-0001
Flywheel Assembly
AK58-00090-0002


Bracket Leveler
0K58-01083-0000
Pivot Pin
0K58-01098-0000
Flat Washer (4)
0017-00104-0190
Lock Washer (4)
0017-00104-0333
Hex Nut (4)
0017-00101-1627
Stop Nut
0K58-01099-0000
Leveling Foot
0K58-01110-0000


Mounting Bolt
0017-00101-0974
Flat Washer
0017-00104-0043
Polley V Pulley 8"
0K58-1105-0000
Lock Washer
0017-00104-0005
Front Roller
0K58-01001-0001
Hex Bolt
0017-00101-1632
Flat Washer
0017-00104-0330


Lens Cover
Mounting Screw (2)
0017-00101-0824
Heart Rate Electrode Kit
GK20-00002-0005
Lens Cover Assembly
0K58-01103-0000
Ergo Bar Gasket (2)
0K58-01347-0000



Voltage	Power Cable Part No.	Breaker AMP/Part No.
100v	AK58-00378-0000	None
200v	AK58-00379-0000	2 AMP/0017-00003-0626
220/230v	AK58-00379-0001	2 AMP/0017-00003-0626
240+	AK58-00379-0001	2 AMP/0017-00003-0626


HR Sensors Cable
AK58-00041-0001
Coax-Cable
AK32-00020-0001
E-STOP SWITCH
END SESSION SWITCH
POLAR PCB
ACCESS PANEL
VIDEO INPUT (COAX)
Polar & Stop switches
AK58-00274-0000
MACHINE INTERFACE BOARD
LCD INTERFACE BOARD
Flat-FlexCable
118E-00001-0172
Inverter Cable Assy
AK32-00032-0000
TOUCH SCREEN (3M)
LCD (SHARP)
BACK-LIGHT
AUDIO
HEADPHONE JACK
Cable Assembly Stub
AK58-00273-0000
Headphone Jack Cable
AK32-00009-0000
Main Console Cable
AK58-00034-0000
CAPACITOR BOARD
Cap Board Cable
AK58-00077-0001 4-Wire
AK58-00181-0000 3-Wire
Cable MTR-CNTR Interface
AK58-00035-0001
Level & Home
Switch Cable
AK58-00027-0000
0% SWITCH
WAX/LIFT POWER SUPPLY BOARD
MOTOR CONTROLLER BOARD
Speed Sensor Cable
AK58-00043-0000
Frame Tag Cable
AK58-00030-0000
EXTERNAL MEMORY FRAME TAG
LIFT MOTOR
WAX PUMP MOTOR
MOTOR
SPEED PICK-UP
Wax Pump
Cable
AK58-00029-0000
Cable Motor Drive Extension
AK58-00042-0002 DOM
AK58-00042-0003 Forn